



With the contents and the process of manufacturing uncapped WPC boards/planks, water stains on the product over a period of time are possible.

**The possible causes of water stain on the uncapped WPC planks are:**

1. Lubricant from the extrusion process
2. Dust from the factory
3. Not enough sun exposure

**The process to remove water stains:**

1. Scrubbing the deck with an Oxygenated cleaner or Oxalic acid cleaner.
2. Use a firm hard bristle deck brush.
3. Rinse off with water until clear.
4. Wipe excess water off with a towel wrapped around the deck brush bristles.
5. The deck will dry quickly in the sun shine with no pooling and color marks.
6. This processes may need to be repeated 2-3 times to completely remove the water stains.
7. If the water stains cannot be removed by above process, sanding the water stains with 120 or higher grit fine sand paper should remove the stains fairly easy.

**Special Notes:**

On water stains free boards and planks, waterproof deck sealer can be applied to prevent water stains for longer period.